

RCT 50 pin Data Sharing Cable Pinouts page 1

50M connector	50M connector
Pin	Pin
1	18
2	19
3	20
4	21
5	22
6	23
7	24
8	25
9	**
10	**
11	**
12	**
13	**
14	**
15	**
16	**
17	**
18	1
19	2
20	3
21	4
22	5
23	6
24	7
25	8
26	43
27	44
28	45
29	46
30	47
31	48
32	49
33	50
34	**
35	**
36	**
37	**
38	**
39	**
40	**
41	**
42	**
43	26
44	27
45	28
46	29
47	30

**=Pin Not Connected

RCT 50 pin Data Sharing Cable Pinouts page 2

50M connector	50M connector
Pin	Pin
48	31
49	32
50	33

**=Pin Not Connected