

```

### Log file for this test: /afs/hep.wisc.edu/cms/RCTlog/daffodil/RC_2004-08-26
.log ### Location of log file

#####
##### RC Test 5f - Backplane data paths #####
### Test run on 2004-08-26_18:21:48
### HOST computer is: daffodil
### Run in vmedia kumac: rc_backplane_path_slot1.txt
Please fill in the backplane data paths CHECKLIST.
#####

!!!! RC to be tested has to be in slot 1 !!!! IMPORTANT!
Device to open: /dev/btp96
Device to open: /dev/btp160 SBS successfully booted and
Device to open: /dev/btp64 talked to the cards in the crate
Enter command (help for usage)> The CCC, 1 EIC in slot 2, 6 RCs and
RCT boot succeeded with 9 cards. the RC to be tested in slot 1 should be plugged in
Enter command (help for usage)> Enter command (help for usage)> Enter command (h
elp for usage)>
Zero memories first.
Device to open: /dev/btp96
Device to open: /dev/btp160
Device to open: /dev/btp64
RCTCrate::initialize() : vmeReset() successful
RCTCrate::initialize() : Defined RCTClockControlCard 10000000
RCTCrate::initialize() : Defined RCTReceiverCard with address 12000000
RCTCrate::initialize() : Defined RCTReceiverCard with address 14000000
RCTCrate::initialize() : Defined RCTReceiverCard with address 16000000
RCTCrate::initialize() : Defined RCTReceiverCard with address 18000000
RCTCrate::initialize() : Defined RCTReceiverCard with address 1b000000
RCTCrate::initialize() : Defined RCTReceiverCard with address 1d000000
RCTCrate::initialize() : Defined RCTReceiverCard with address 1f000000
RCTCrate::initialize() : Defined RCTElectronIsolationCard with address 15000000
rctCrateTest: initialize() succeeded
Cards in the crate are: 54ba
RCTCrate::doZeroPatternTest() : Loading RC (f500, 12000000)
RCTCrate::doZeroPatternTest() : Verifying RC (f500, 12000000)
RCTCrate::doZeroPatternTest() : Loading RC (fa00, 14000000)
RCTCrate::doZeroPatternTest() : Verifying RC (fa00, 14000000)
RCTCrate::doZeroPatternTest() : Loading RC (0, 16000000)
RCTCrate::doZeroPatternTest() : Verifying RC (0, 16000000)
RCTCrate::doZeroPatternTest() : Loading RC (f600, 18000000)
RCTCrate::doZeroPatternTest() : Verifying RC (f600, 18000000)
RCTCrate::doZeroPatternTest() : Loading RC (f700, 1b000000)
RCTCrate::doZeroPatternTest() : Verifying RC (f700, 1b000000)
RCTCrate::doZeroPatternTest() : Loading RC (fe00, 1d000000)
RCTCrate::doZeroPatternTest() : Verifying RC (fe00, 1d000000)
RCTCrate::doZeroPatternTest() : Loading RC (f800, 1f000000)
RCTCrate::doZeroPatternTest() : Verifying RC (f800, 1f000000)
RCTCrate::doZeroPatternTest() : Loading EIC (b100, 15000000)
RCTCrate::doZeroPatternTest() : Verifying EIC (b100, 15000000)
rctCrateTest: All tests successful
Now start vmedia script rc_backplane_path_slot1

*****
*** this is vmedia script rc_backplane_path_slot1.txt ***
*****
for this test, the rc has to be in slot 1 Important
Continue <return> ? Exit <Ctrl-D> ? type <return> here
this rc has barcode
Device to open: /dev/btp96
Device to open: /dev/btp160
Device to open: /dev/btp64

```

Check that the verification doesn't fail. When it does, leave the script (Ctrl-D) and vmedia (exit) and redo >run_RC_test5f

```
14000006 -> FA05 Compare this number with the RC bar code
Continue <return> ? Exit <Ctrl-D> ? type <return> here
for this test, the crate has to be loaded with all seven rc's Important
12000006 -> F565
14000006 -> FA05
16000006 -> 0060
18000006 -> F600
1B000006 -> F760 These
1D000006 -> FE00 values
1F000006 -> F820 should
12000000 -> 0202 be
14000000 -> 0202 read
16000000 -> 0202 back
18000000 -> 0202
1B000000 -> 0202
1D000000 -> 0202
1F000000 -> 0202
initial setup done.
start with paths for corner sharing.
put a 68-pin cable from rc 0 j4 to rc 1 j4 Follow these directions, no need to first power down
Continue <return> ? Exit <Ctrl-D> ?
sw corner -- next ? Should see a "1" on U66, pins 24, 28, 4, 6
Continue <return> ? Exit <Ctrl-D> ?
nw corner -- hit return Should see a "1" on U66, pins 23, 27, 3, 5
Continue <return> ? Exit <Ctrl-D> ? type <return> here
VMEDia>
VMEDia> exit type 'exit' here
Bye

##### RC Test 5f End #####
```